

DISPLAY CODE		ERROR			
F	E	Description	Monitoring time	Frequency	Conditions
1	E2	Input referring to temperature sensor missing	1 minute	Always	
F3	E0	Temperature sensor open	1 min.	Always when oven is operating	Temperature too high (depends on EEPROM contents)
	E3	Short-circuited temperature sensor	1 min.	Always when oven is operating	Temperature too low (depends on EEPROM contents)
F4	E0	EEPROM Error	64 attempts / message + 40 attempts / header (up to 2 min.)	Every time an EEPROM area is accessed	Wrong data control or EEPROM does not answer
F5	E2	Door block that does not lock/ unlock	TBD	Always (1)	When piloted, the door block is not in the requested position.
F8	E0	Potentiometer error	1 min.	Always	Analog voltage out of valid interval
F	FF	Unknown error	Immediate	Always	Internal error