

FOR INFORMATION ONLY

DISHWASHER ERROR CODE E9 - OVERFILLING


E9 – Max tank water level exceeded (only versions with turbine)

This alarm is generated when the appliance is lacking a full tank signal from the pressure switch and a volume of water totalling 7,5 litres is measured from the flow meter. The machine will stop the cycle and displays an E9 error code.

This defect can be caused by, but not only, a defective pressure switch which is sometimes referred to as a pressostat level and is located underneath the appliance.



An example of a flow meter.



An example of a pressure switch.